

Room Wash Down

Rubbish

- Remove rockwool cubes from slabs and bag cubes in black sacks
- Remove all slabs and cube bags from the room and discard outside facility
- Vacuum all plant material up from floor and benches and discard

PPE

- Use gloves, glasses, face mask

Foam Benches

- **Mix:** 30ml foam detergent and 970ml water in foam bottle.
- **Connect:** Foam gun to hose, turn on full
- **Apply:** Foam benches evenly (wet cover is best for salt removal)
- **Wait:** 10 minutes (keep wet)
- **Action:** Scrub stubborn salt with nylon brush
- **Rinse:** Hose thoroughly

Bleach Benches

- **Mix:** 1ltr bleach (5% sodium hypochlorite) and 9ltr water in the “35ltr Sanitiser Sprayer”
- **Apply:** Spray benches evenly, avoid spraying on metal
- **Wait:** 10 minutes (keep wet, do not let dry)
- **Action:** Scrub stubborn algae with nylon brush
- **Rinse:** Hose thoroughly to protect metal surfaces

Sanitise Benches

- **Mix:** 1ltr H₂O₂ (60%) and 9ltr water in the “35ltr Sanitiser Sprayer”
- **Apply:** Spray benches evenly, avoid spraying on metal
- **Wait:** 10 minutes
- **Rinse:** Hose thoroughly to protect metal surfaces

Sanitise Drippers

- **Mix:** **18ltr H2O2** (60%) and **162ltr water** in the “Dripper Sanitiser Tank”
- **Apply:** Open the room’s sanitiser valve in pump room
- **Growlink or HA:** Turn on room “Sanitiser Program” (to open all solenoids in room for 5 mins.)
- **Wait:** 5min soak
- **Finish:** Close the room’s sanitiser valve in pump room

Flush Drippers

- **Growlink or HA:** Turn on room “Flush Program” (to open all solenoids in room for 5 mins.)
- **Wait:** 3 mins to flush drippers
- **Flush:** Open flush valve at the end of each bench to flush any larger debris.
- **Finish:** Close flush valve at the end of each bench

Floor

- **Mix:** **25ml bleach** (5% sodium hypochlorite) and **5ltrs water** in mop bucket
- **Apply:** Mop floor, avoid metal

Clean Other Equipment

- Clean drains and runoff bucket
- Check whipkit filters, clean if necessary
- Check carbon filters, if dusty/dirty replace pre-filter covers
- Empty wetvac and clean
- Place all equipment back in its correct home