

Stock Tank Reset

Procedure

1. Preparation

- Put **Bluelab Pro Controllers** into “**Monitor**” mode.

2. Empty

- Discard any remaining stock solution.
- Rinse the tank thoroughly with water blaster / clean water.
- Wipe out any visible mold or residue with microfibre cloth.

3. Sanitize

- Use a **microfibre cloth with isopropyl alcohol** to wipe all internal surfaces of the tank.
- Wipe down the **doser feed line**, bolt and lid.

4. Reset

- Place the **doser feed line** back at the bottom of the tank.
- Refill the tank following the “**Nutrient Stock**” instructions.
- Switch **Bluelab Pro Controllers** back into “**Control**” mode.